


## CYLINDER, CRANKCASE, PISTON



## CYLINDER, CRANKCASE, PISTON


Key	Lv	Part no.	Part description	Quantity
1		A014-000040	DECOMP,ASM	1
2		V805-000220	BOLT, TORX 5	4
3		A130-001740	CYLINDER	1
4		A202-000220	BELLOWS, INTAKE	1
5		A206-000021	HOLDER, BELLOWS	1
6		V805-000000	BOLT, TORX 5	3
7		V100000630	GASKET,CYL	1
8		P021-036680	PISTON KIT	1
9	+	A101-000590	RING, PISTON	1
10	+	100015-32330	CIRCLIP, PISTON PIN	2
11	+	V609-000000	PIN,ENG 11	1

12	+	V556-000000	BEARING,NEEDLE 11	1
14		100142-30830	KEY, WOODRUFF	1
15		P021-036690	CRANKCASE KIT	1
16	+	V508-000010	SEAL,OIL 15	2
17	+	100215-02830	PIN, DOWEL	2
18	+	94036-46202	BEARING BALL	2
19	+	V102000210	GASKET,CRANKCASE	1
33	+	437239-14730	NIPPLE	1
34	+	436114-13930	VALVE, CHECK	1
38	+	V205-000400	BOLT,8	2
20		V805-000010	BOLT, TORX 5	2
21		V805-000020	BOLT, TORX 5	4
22		V420003800	CUSHION	2
23		A239-000060	PIPE, INTAKE	1
24		A011-001100	CRANKSHAFT,ASY	1
25		V359-000060	COLLAR,16	1
26		V805-000000	BOLT, TORX 5	1
27		E106-000150	GUIDE,AIR	1
28		P021-016030	CAP, OIL	1
29	+	131051-19830	LINK	1
30	+	900246-03008	SCREW 3*8	1
31	+	131050-19830	RETAINER, LINK	1
32	+	900720-00028	O-RING 28	1
35		V805-000170	BOLT, TORX 5	1
36		V141-000090	GROMMET,PLUG	1

## CYLINDER, CRANKCASE, PISTON

Key	Lv	Part no.	Part description	Quantity
37		132115-01461	GROMMET	1
39		P021-036670	FIXTURE, VALVE KIT M	1
41		900212-04014	SCREW 4*14	2
42		V804-000050	BOLT, TORX 4	6
43		A202-000210	BELLOWS, INTAKE	1
44		V376001780	SPACER	1

AIR CLEANER, CARBURETOR




AIR CLEANER, CARBURETOR

Key	Lv	Part no.	Part description	Quantity
1		V804-000030	BOLT, TORX 4	5
2		A301-000030	PLATE, MUFFLER	1
3		A313-001670	GUIDE, EXHAUST	1
4		A313-001041	GUIDE, EXHAUST	1
5		A310-000090	SCREEN, ARRESTOR	1
6		A300-001560	MUFFLER, EXHAUST	1
7		V104001770	GASKET, EXHAUST	1
8				1
9				1
20	+	A219-000060	SHUTTER, AIR	1
10		V805-000030	BOLT, TORX 5	2

14		A232-001400	LID,CLEANER	1
15		A235-000200	KNOB,CLEANER LID	1
16		A160-002310	COVER,CYLINDER	1
17		A239-000070	PIPE, INTAKE	1
18		V341-000140	WASHER,SQUARE	1
19		V805-000000	BOLT, TORX 5	3
21		V805-000210	BOLT, TORX 5	2
27		V855-000000	BOLT, TORX 5	2
28				1
29		V142000070	GROMMET,DUST	1

MAGNETO, STARTER




MAGNETO, STARTER

Key	Lv	Part no.	Part description	Quantity
1		A427-000013	CAP, SPARK PLUG	1
2		A426-000010	TERMINAL, SPARKPLUG	1
3		A429-000040	COVER, CAP	1
4		A425-000000	SPARKPLUG	1
5		V475006660	TUBE	1
6		156110-04920	BUSHING	1
7		V485001091	LEAD	1
8		A411-001190	COIL, IGNITION	1
9		V805-000000	BOLT, TORX 5	2
10		A409-000360	ROTOR, MAGNETO	1
11		900515-00008	NUT, FLANGE 8	1

12		177234-35430	SPRING, RETURN	2
13		177247-04630	SPACER, RATCHET	2
14		177218-19830	PAWL, STARTER	2
15		900603-00005	WASHER 5	2
16		V835-000000	BOLT, TORX 5	2
17		A172-000842	COVER,FAN	1
18		P021-015163	STARTER ASY	1
19	+	V805-000130	BOLT, TORX 5	1
20	+	177214-02830	WASHER	1
21	+	A506-000110	REEL, ROPE	1
22	+	177226-07060	ROPE, STARTER	1
23	+	A503-000030	PLATE, STARTER	1
24	+	177220-35430	SPRING, REWIND	1
25	+	A511-000071	GRIP, STARTER	1
29		V805-000010	BOLT, TORX 5	4

HANDLE



HANDLE

Key	Lv	Part no.	Part description	Quantity
1		C400-001040	HANDLE, FRONT	1
2		V806-000000	BOLT, TORX 6	1
3		V805-000010	BOLT, TORX 5	4
4		V456-000080	HOLDER, SPRING	1
5		V805-000000	BOLT, TORX 5	1
6		V450-000730	SPRING, COMPRESSION	1
7		V805-000000	BOLT, TORX 5	2
9		C617-000361	STOPPER	1
10		V471003080	PIPE	1
11		132013-09820	CLIP	1
12		131205-19831	STRAINER, FUEL	1




13		132012-02960	PIPE, FUEL	1
14		132115-01461	GROMMET	1
15		V131-000180	GROMMET, NEEDLE	1
20		C454-000470	ROD, THROTTLE	1
21		178090-37930	LOCKOUT, T. CONTROL	1
22		C450-000360	CONTROL, THROTTLE	1
23		V452-000260	SPRING, TORSION	1
24		900345-40025	PIN, SPRING 4*25SUS	1
25		C411-000001	LID, HANDLE	1
26		V130-000030	GROMMET, CHOKE	1
27		A241-000220	KNOB, CHOKE	1
28		C410-001000	HANDLE, REAR	1
29		A440-001190	SWITCH, ON OFF	1
30		V485-001101	LEAD	1
31		150114-04920	BUSHING	1
32		P021-016040	CAP, FUER ASSY	1
33	+	131051-19830	LINK	1
34	+	900246-03008	SCREW 3*8	1
35	+	131050-19830	RETAINER, LINK	1
36	+	900720-20029	O-RING 29	1
37		V805-000010	BOLT, TORX 5	2
38		V456-000090	HOLDER, SPRING	1
39		V450001630	SPRING, COMPRESSION	1
40		V805-000010	BOLT, TORX 5	1
41		A359-000000	COVER, VENT	1

## HANDLE

Key	Lv	Part no.	Part description	Quantity
42		13130056431	VENT ASSEMBLY, FUEL	1
43		V450-000770	SPRING, COMPRESSION	1
44		V456-000101	HOLDER, SPRING	1
45		V806-000000	BOLT, TORX 6	1
46		V804-000000	BOLT, TORX 4	1
47		132013-26630	CLIP	1
49		A472-000090	CAP	1

CLUTCH, SPROCKET



CLUTCH, SPROCKET


Key	Lv	Part no.	Part description	Quantity
1		C320-000410	LEVER, BRAKE	1
2		V805-000000	BOLT, TORX 5	5
3		V356-000440	COLLAR,10	2
4		C345-000282	COVER,BRAKE	1
5		C334-000110	CONNECTOR, BRAKE	1
6		V356-000470	COLLAR,10	1
7		V452-000400	SPRING,TORSION	1
8		V376-000450	SPACER	1
9		C328-000121	BAND, BRAKE	1
10		93050-30080	ROLLER	1
11		V450-000740	SPRING,COMPRESSION	1

12		V583-000130	RING	1
13		V307000410	WASHER,CIRCULAR 10	1
14		175114-12530	SPROCKET, RIM .325	1
15		A556-001310	DRUM, CLUTCH	1
16		V555000160	BEARING,NEEDLE 10	1
17		A056-000220	CLUTCH ASY	1
18	+	A552-000110	HUB, CLUTCH	1
19	+	P021-007050	CLUTCH SHOE SET	1
20	+	V451-000500	SPRING,TENSION	3
21		A551-000110	PLATE, CLUTCH	1
22		V358-000090	COLLAR,14	1
23		900701-00015	CIRCLIP 15	1
24		437210-30830	PIPE, OIL	1
25		132013-09820	CLIP	2
26		V470001790	PIPE	1
27		C022-000051	AUTO-OILER ASSEMBLY	1
28		V804-000000	BOLT, TORX 4	2
29		V652-000050	GEAR,WORM	1
30		C305-000390	PLATE,SPROCKET GUARD	1
31		V203-000110	BOLT,5	1
32		C309-000150	TENSIONER, CHAIN	1
33		V651-000001	GEAR,BEVEL	1
34		V651-000011	GEAR,BEVEL	1
35		V355-000270	COLLAR,8	1
36		91325-03005	SCREW	1

## CLUTCH, SPROCKET

Key	Lv	Part no.	Part description	Quantity
37		C305-000400	PLATE, SPROCKET GUARD	1
38		C300-000810	GUARD, SPROCKET	1
41		V265-000250	NUT	2
43		C302-000010	PAD, GUARD	1
44		436205-14730	STRAINER, OIL	1
45		V341000170	WASHER, SQUARE	1
46		C603-000220	PLATE, SIDE	1
47		V804-000000	BOLT, TORX 4	1
48		V311-000090	WASHER, CIRCULAR 16-1	1
49		C518-000150	BRACKET, PIPE	1


TOOLS



## TOOLS

Key	Lv	Part no.	Part description	Quantity
1		V805-000000	BOLT, TORX 5	2
2		C304-000180	SPIKED	1
3		C310-000010	CATCHER, CHAIN	1
5		X698-000050	TOOL, CASE	1
6		X602-000080	TOOL, WRENCH	1
7		895812-03930	DRIVER, SCREW 50	1
9		X605-000050	TOOL, L WRENCH	1

CARBURETOR



CARBURETOR

Key	Lv	Part no.	Part description	Quantity
				1
2	+	P003004040	COVER,AIR VALVE BODY	1
3	+	P003-002020	VALVE AIR	1
4	+	P003-002050	WASHER	1
6	+	P003-002060	SEAL DUST	1
7	+	P003-002000	COVER DUST	1
8	+	P003-002040	SPRING RETURN	1
10	+	P003-002030	SCREW	1
11	+	123114-40630	SCREW	4
12	+	123149-26030	WASHER	4
13	+	P003-002080	LINK ROD	1



14	+	123127-15030	RING	3
15	+	123114-38830	SCREW	4
17	+			1
18	+			1
20	+			1
21	+	123116-10530	VALVE, THROTTLE	1
22	+	P003004280	SCREW	1
23	+	P003-002150	SPRING	2
24	+	123185-39130	PISTON ASSY	1
25	+			1
26	+	P003-002110	GASKET PASSAGE	1
27	+	P003-002160	PLATE PASSAGE	1
28	+	P003-000100	GASKET, PUMP	1
29	+	123112-40630	DIAPHRAGM, PUMP	1
30	+			1
31	+	123126-10631	SCREEN, INLET	1
32	+	123139-05560	SCREW, M. LEVER PIN	1
33	+	123137-19830	VALVE, INLET NEEDLE	1
34	+	123122-05560	SPRING, METER. LEVER	1
35	+	123123-03930	LEVER, METERING	1
36	+	123138-03930	PIN, METERING LEVER	1
37	+	123140-27230	GASKET, M. DIAPHRAGM	1
38	+	P003-001850	DIAPHRAGM, METERING	1
40	+	123142-03930	COVER, M. DIAPHRAGM	1
42	+	123110-40630	SCREW, PUMP COVER	4

## CARBURETOR

Key	Lv	Part no.	Part description	Quantity
43	+	123178-15030	PLUG, FRICTION	1
50	+	P003-001510	LEVER-FAST IDLE	1
51	+	P003004060	LEVER, CHOKE	1
52	+	P003-002200	VALVE, CHOKE	1
53	+			1
54	+			1
55	+			1
56	+			2